







## Magnetic Lock Wiring Instructions


Model	Size (unit:mm)	Magnetic Plate (unit:mm)	Voltage	Current	Holding Force	Door
EL-100	79Lx40Wx23H	75Lx31Wx10H	DC12V	12V/160mA	60kg(100Lbs)	Single Door
			DC24V	24V/200mA		
EL-H100	114Lx35Wx23H	75Lx31Wx10H	DC12V	12V/160mA	60kg(100Lbs)	Single Door
			DC12V	24V/200mA		




### Remark:

A: Please don't fix the screw(screw of armature plate) tightly, let the rubber ring maintain proper elasticity.


# Installation



Standard Installation




Z Bracket Installation




UL Bracket Installation

# Wiring Diagram



POWER 12VDC 100mA



12VDC



24VDC



S4A Industrial Co., Limited

Address: The 2nd floor, Jinmin'an Industrial Zone, #529, Bulong Rd.  
Bantian St. Longgang Dist. Shenzhen, PRC.. CN 518131



Tel: +86 755 29450011

[www.s4a-access.com](http://www.s4a-access.com) / Email: [sales@s4a-access.com](mailto:sales@s4a-access.com)  
Mob/Whatsapp/Wechat/Viber: +86 134 1050 0721